

Barcode Scanner  
User Manual



**System Setting**



**Communication Interface**



**Scanner Mode**



**Keyboard case control**



**Terminator**



**Keyboard language**



**Beep**





W010F01  
Start



W010F01  
Start



W010F01  
Start



W010F01  
Start

### Barcode Enable and Disable



Enable all Barcodes



W016601  
Enable EAN-13



W017401  
Enable Code 39



W06C00  
Disable Interleaved 2 of 5  
check digit verification



WFFD982  
Disable all Barcodes



W016600  
Disable EAN-13



W017400  
Disable Code 39



W016101  
Enable Code 128



W036B02  
Enable UPC-A



W036203  
Enable GS1-128



W016100  
Disable Code 128



W036B00  
Disable UPC-A



W036200  
Disable GS1-128



W016501  
Enable EAN-8



W016901  
Enable UPC-E



W016C01  
Enable Interleaved 2 of 5



W016500  
Disable EAN-8



W016900  
Disable UPC-E



W016C00  
Disable Interleaved 2 of 5



W010F00  
End



W010F00  
End



W010F00  
End



W010F00  
End